



Mirasys Universal Data Driver



Mirasys Universal Data Driver

Table of Contents

1. Universal Data Driver guide.....	3
2. How to configure UDD text channel.....	14
3. UDD4Demo.xml.....	29

Mirasys Universal Data Driver

1. Universal Data Driver guide

Universal Data Driver Idea

Universal data driver (UDD for short) is a configurable text data capture and transaction management interface for Mirasys VMS.

It has several communication interfaces to interact with text data sources, namely TCP/IP and HTTP client and server, and UDP/IP and serial (RS-232) server protocols. There is one special case for RTSP transaction messages. It is used for UDP technologies' IP camera VCA metadata event capturing.

Transaction messages can be either text strings (ASCII messages) or XML formatted messages.

Text format validation and parsing are done using regular expressions (Boost RegEx). XML messages are validated using XSD and parsing using XPath notation. For binary messages and transaction sources requiring proprietary parsing and special communication protocol (for example SIA or ContactID protocols), there is a possibility to use custom validation (pre-processing) in custom DLL (dynamic link library).


All channels support UTF-8 and UTF-16 text as well as binary data formats (custom validation).

As a result transaction events can trigger alarms. By default, all transaction messages are stored in a text data channel.

Text data content can later be searched using the Spotter text search plugin and be used to synchronize video and audio playback.

COMMUNICATION LAYER CLASS DIAGRAM

Mirasys Universal Data Driver



DATA VALIDATION AND MAPPING INTERFACE

STRUCTURE OF CONFIGURATION FILE FOR SIMPLE TEXT ALARM DATA

```

<?xml version="1.0" encoding="UTF-8"?>
<root>
  
```

This example describes validation and message mapping configuration for text data alarms that a Piccolo alarm system can send to the driver.

CHANNEL CONFIG

Channel Config section defines the **linefeed** value of the incoming messages, i.e. the message separator.

Mirasys Ltd - C1CD, Vaisalantie 2-8, 02130 - Espoo, Finland

Tel +358 (0)9 2533 3300 - info@mirasys.com - www.mirasys.com

Mirasys Universal Data Driver

Typically Windows applications terminate messages to carriage return and linefeed (CR+LF = 0x0D0A). Unix systems (like IP cameras) typically use only linefeed (LF = 0x0A).

In some cases messages are not separated, i.e. source system is sending data in bursts.

In that case, the linefeed value should be left empty ("") and use text type parsing to match the incoming character stream.

UDD channel reader can ignore selected characters or byte values to clean the data and help to parse.

Tag **ignored** lists all the characters that should be filtered out before passing them to the UDD parsing phase.

The most common ignored value is a NULL byte, i.e. 0x00.

When the text channel is active and the text data window is open in Spotter, all incoming messages are echoed in it.

If the user would like to control the view, it is possible to clear the window when needed.

This can be done by sending the **clearscreen** string to the text channel.

```
<channelConfig>
<linefeed value="0x0d0a"/>
<ignored value="0x00"/>
<clearscreen value="----"/>
</channelConfig>
```

Validation

Different validation methods are described under a validation element.

The given attribute for regex contains a regular expression string to be used to validate text data ("*" at the end means 0 or many of the before defined character set).

```
<validation>
<regex value=".*/>
</validation>
```

For XML formatted messages XSD (XML schema) validation type is used:

```
<validation>
<xsd value="MySchema.xsd"/>
</validation>
```

Mirasys Universal Data Driver

If the .xsd file is defined, this file will be used for incoming XML message validation. But the "value" attribute can be empty - in this case, the common validation will be used: only checking that the incoming message has the correct XML format.

Log messages in the DVRLog.txt

Detailed logging mode can be enabled by inserting the following option in the XML configuration file.

Logging level parameters are:

- 0: no writing to dvrlog.txt
- 1: only error messages, error and info messages.

To enable additional message writing and input data packet storing, you should add

<additionalDebug> tag to logging element with the attribute value="yes".

Data packets read into the text channel will be written into a DVR folder file named "Debug_UDD_Packets.bin".

Additional text channel info will be written into the file "Debug_UDD_Log.txt" in the same folder.

```
<logging>
<level value="2"/>
<additionalDebug value="yes"/>
</logging>
```

MESSAGE CONTENT PARSING – UDDXMLMAPPER ELEMENT

Transaction event message content parsing is defined in **uddXmlMapper** element.

Incoming messages can be ASCII strings or well-formed XML.

Binary messages will need pre-processing before UDD can handle them.

Typically pre-processing from binary format to internal XML format is done in a separate proxy service (for example PaxtonProxy or BoschIVAproxy) or in UDD custom validator (for example GalaxyDataValidator.DLL or TexecomDataValidator.DLL).

Mirasys Universal Data Driver

```
<uddXmlMapper version="2">
```

Message definitions – messageType element

Inside uddXmlMapper element first sub-element is **messageType**.

The message type element defines the incoming message content format (ASCII **text** or **XML**).

```
<messageType value="text" parsing="regex">
```

Inside message type elements are messages with their content references. ASCII text parsing tagging is defined using regular expressions and XML parsing using XPath notation to reference tags ("+" at the end of a group means 1 or many of the before defined character set).

```
<messageType value="text" parsing="regex">
<message number="1" value="alarm">
<param number="1" value="([a-zA-Z]+) (.+)" group="1"/>
<param number="2" value="([a-zA-Z]+) (.+)" group="2"/>
</message>
</messageType>
```

In the above example, ASCII text has three interesting parts; a string of letters, a string of any characters and a string of numbers.

Strings are separated by spaces.

If the incoming message would be (followed by the defined line feed)

then

group="1" match "start" group="2" match "low" group="3" match "4"
rest of the message would be ignored from a matching point of view.

If the incoming XML message having the same kind of information would be (followed by the defined line feed)

```
<?xml version="1.0" encoding="UTF-8"?>
<alarm>
  <rule>start</rule>
  <type level="4">low</type>
  <info>this is normal</info>
</alarm>
```

then

"alarm/rule" match "start" "alarm/type" match "low" "alarm/type/@level" match "4"

Note that XML tag attributes are denoted using @ sign in front of the attribute name.

Mirasys Universal Data Driver

Message content constants – Constants element

These constant arrays contain values that can be used in the message handling rules section.

```
<constants>
<array name="Rules" params="AT">
<value>start</value>
<value>stop</value>
</array>
<array name="AlarmType" params="AT">
<value>ACCESS CONTROL ALARM 1</value>
<value>ACCESS CONTROL ALARM 2</value>
<value>ACCESS CONTROL ALARM 3</value>
</array>
</constants>
```

In this example, incoming messages contain “Rules” strings that have values “start” and “stop”. Params “AT” and “TL” mean that these values will be used at least in two different kinds of rule definitions in the UDD rules element.

Action rules - Rules element

Action rules, i.e. how to handle incoming transaction messages, are defined in Rule's element.

There can be more than one type of message and its rules, but typically UDD is configured to handle messages only in one format.

However, one message format usually has several rules and events defined.

```
<rules>
<message number="1" value="alarm" alwaysShowText="yes">
<param number="1" reference="1" value="$Rules" operator="eq" id="AT">
<and number="1" reference="2" value="$AlarmType" operator="eq"/>
<action number="1" type="event" value="$Rules $AlarmType alarm" />
</param>
</message>
</rules>
```

In this example <message number="1" value="alarm" refers to the messageType element and its message definition.

Mirasys Universal Data Driver

Note, that in text format messages the message tag attribute in messageType has to have a name (value="alarm").

In XML format messages this value is by default name of the root tag, in this example alarm (value="**alarm**/rule").

Message tag attribute alwaysShowText="yes" means that all incoming messages will be shown in the text channel device window.

Message tag attribute handleParameters=" all" means that for the incoming message all rules are run through. By default, UDD stops to the first matching rule. If there were more than one message format handled in the rules element, then message elements will have an ascending number attribute number="1", number="2", etc.

Rules for the message are defined in the param element. Param elements have an ascending number attribute.

Param element reference attribute is a sequence number of message tags (see messageType/message element above, in the example group="1" match "start" or "alarm/rule" match "start"). So in the example above reference="1" would contain the value "start".

Param tag attribute can be either constant value="start" or a reference to constant array (in constants element) value="\$Rules".

Using constant arrays UDD automatically expands rules using the values of constant arrays during runtime.

So, the operation would be the same (in the above example) either using arrays (Rules array containing strings "start" and "stop") or manually configuring two rules params

```
<param number="1" reference "1" value="start" operator="eq">
<param number="2" reference "1" value="start" operator="eq">
```

Comparison operators that can be used as Boolean operators are:

eq	= [default]
gt	>
ge	>=
lt	<
le	<=
neq	!= not equal
contains	finds configuration parameter value as substring in the incoming message parameter value
contained	finds incoming message parameter value as substring in the configuration parameter value, this operator is supported in the 2.13.6.0 version of the UDD or higher

Each parameter can have the "type" attribute which is used for correct text values conversion for comparing. Currently, the following types are supported:

- type="integer"
- type="float"

Mirasys Universal Data Driver

- type="string"

If the "type" attribute is not specified, the "string" type is used by default. The rule per message can contain one or more parameters, and these parameters can refer to one or more parameters defined in the messageType element as described above.

This example configuration XML for a simple text alarm data has only one parameter per message, so message parameters in message rules refer to parameter 1.

```
<rules>
  <message number="1" value="Alarm cam001">
    <param number="1" reference="1" type="string" value="Alarm
cam001">
```

Zero or more actions can be associated with message parameters. Currently, defined actions are "event" to trigger events, "data" to send data, and "metadata" to send metadata to DVR.

```
<action number="1" type="event" value="Alarm cam001" />
<action number="2" type="data" value="Alarm cam001 data" />
<action number="3" type="metadata" value="" />
```

For metadata one additional attribute can be used - "metadatatype". If it is specified it allows to configure metadata type:

- "xml" - XML metadata format
- "udpvca" - special UDP VCA metadata format
- "textevent" - text event metadata format
- "other" - other metadata formats

If the "metadatatype" attribute is not specified the default text channel format is used.

The parameters can also have an associated search tag. If a search tag type attribute has been omitted, it is set by default to be SEARCH_TAG_TYPE_TEXT.

Mirasys Universal Data Driver

```

<searchtag value="Alarm cam001" />
</param>
</message>
<message number="2" value="Reset 001">
<param number="1" reference="1" type="string" value="Reset
001">
    <action number="1" type="event" value="Reset 001" />
    <searchtag value="Reset 001" />
</param>
</message>
<message number="3" value="Alarm cam002">
<param number="1" reference="1" type="string" value="Alarm
cam002">
    <action number="1" type="event" value="Alarm cam002" />
    <searchtag value="Alarm cam002" />
</param>
</message>
<message number="4" value="Reset 002">
<param number="1" reference="1" type="string" value="Reset
002">
    <action number="1" type="event" value="Reset 002" />
    <searchtag value="Reset 002" />
</param>
</message>
</rules>
</ndkXmlMapper>
</root>

```

So what this example configuration will do is to tell the driver that:

- we are expecting incoming data to be textual
- text data must match with the defined regex pattern
- there are four possible message types

For example, if the incoming data is

Alarm cam001

it is validated against regex and matched against defined message types. The match is found with the defined message number 1, so the driver will send an event and "Alarm cam001" data to DVR.

If the incoming data would be

Alarm cam100

it would validate against regex but no matching rule is found, so it would be ignored.

And if the incoming data would be

Alarm ####!

Mirasys Universal Data Driver

it would not validate against a defined regex pattern and would generate an error in the DVR log file.

WHEN STARTING THE INTEGRATION TEST

It is a best practice that before taking the transaction message validation and parsing configuration into use, first test the communication between the two systems.

This way all captured messages will be written directly into the text channel. Select validation mode "None" in the channel configuration dialogue, start transaction counterpart and monitor text channel device window in Spotter user interface.

ADDITIONAL PARAMETERS FOR HTTP SERVER

Additional parameters can be configured for the HTTP server channel in the XML configuration file.

These parameters should be placed to the special section

<HTTPServer></HTTPServer>. Currently, the following parameters are supported:

- "processingType" attribute - the special attribute to determine what part of incoming HTTP request will be processed:
 - All - whole message
 - Headers - only HTTP headers from the incoming message
 - Uri - only HTTP URI string from the incoming message
 - Content - only HTTP content from the incoming message
- <Response> element - the HTTP response message content.
 - If the attribute "send" value is no, the driver will send an HTTP response message without content
 - If the attribute "send" value is yes, the driver will send an HTTP response message with specified content data

Example of additional parameters configuration for HTTP server channel:

Mirasys Universal Data Driver

```
---
<Additional>
  <HTTPServer processingType="All">
    <Response send="true">Response string to send</Response>
  </HTTPServer>
</Additional>
---
```

- type="integer"
- type="float"
- type="string"

If the "type" attribute is not specified, the "string" type is used as default.

```
<param number="1" reference="$Rules" operator="eq" id="AT">
  <and number="2" reference="$AlarmType" operator="eq"/>
  <action number="1" type="event" value="$Rules $AlarmType alarm" />
</param>
```

It is possible to combine more than one content reference using Boolean operator AND. In the example

message content reference="1" ("alarm/rule") and reference="2" ("alarm/type") must both be true ("and" operator) in order to trigger the action event value="\$Rules \$AlarmType alarm".

If the message content would have been for example "alarm/rule" matching "start" and "alarm/type" matching "low", then the trigger "start low alarm" would have been triggered.

2. How to configure UDD text channel

Create UDD configuration file(s); for text validation UDD configuration XML and for XSD validation both UDD configuration file and XSD validation schema.

Hint: good online XML tools can be found from <http://www.freeformatter.com/xml-validator-xsd.html> <http://www.freeformatter.com/xsd-generator.html>

Copy configuration file(s) into DVR folder (for example C:\Program Files (x86)\DVMS\ DVR).


Adding text channel to the Mirasys VMS

1. Open **System Manager**
2. Go to the **VMS servers** tab
3. Open **Text channels**




4. Select first free text channel
5. Click **Add channel**

Mirasys Universal Data Driver




6. Set **Model** to **UniversalDataTcpModel**
7. Enter needed **TCP Port number**(default **40000**)
8. Set **Validation** to **Text**
9. Click **OK**

Mirasys Universal Data Driver



10. Enter the name of the text channel and press **OK**.

Mirasys Universal Data Driver



Editing UDD4Demo.xml

1. Open text editor with admin rights
2. Browse to **C:\Program Files\DVMS\ DVR**
3. Select **UDD4Demo.xml** file
4. Edit


```
<array name="Rules" params="AT">
<value>START</value>
<value>STOP</value>
```
5. Edit


```
<array name="AlarmType" params="AT">
<value>ACCESS CONTROL 1 EVENT</value>
<value>ACCESS CONTROL 2 EVENT</value>
<value>ACCESS CONTROL 3 EVENT</value>
```
6. Save changes and close text editor
7. Open created text channel and rename text channel and click **OK**(Mirasys VMS reloads changes from UDD4Demo.xml)

**In this example, we have edited the UDD4Demo.xml file so that when the below text appears, that will be used as a trigger of the alarm.
All other texts are ignored.**



Mirasys Universal Data Driver

START ACCESS CONTROL 1 EVENT


START ACCESS CONTROL 2 EVENT

START ACCESS CONTROL 3 EVENT

Creating an alarm from the validated text


1. Go to the **VMS Servers\Alarms**
2. Click **New Alarm**
3. Enter the name of the alarm(in this example we are using **START ACCESS CONTROL 1 EVENT, START ACCESS CONTROL 2 EVENT and START ACCESS CONTROL 3 EVENT**)
4. Set **Priority** and **View alarm in profiles**

Mirasys Universal Data Driver




1. Open **Trigger tab**
2. Select **Text data** from the dropdown menu

Mirasys Universal Data Driver




6. Select correct text channel
7. Select alarm trigger from the upper box(this example **START ACCESS CONTROL 1 EVENT**)
8. Enable **Define ending input**, if needed(If Define ending input is set, the alarm will be active until selected input text is received to the text channel)
9. Select correct ending input(this example **STOP ACCESS CONTROL 1 EVENT**)

Mirasys Universal Data Driver




1. Open **Actions** tab
2. Select actions of the alarm from the dropdown menu and add them to the **Visible** box by clicking **Add**

Mirasys Universal Data Driver



1. Open **Calendar**
2. Define, alarm active hours
3. Click **OK**

Mirasys Universal Data Driver



The screenshot shows the 'Alarm Configuration' window with the 'Calendar' tab selected. The left sidebar has buttons for 'General', 'Trigger', 'Actions', and 'Calendar'. Below that are tabs for 'Regular Schedule' and 'Exception days'. The main area is a grid for scheduling an alarm. The columns represent the days of the week: Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, and Sunday. The rows represent hours from 0 ap. to 23 ip. A legend on the left indicates that white cells mean 'Off' and grey cells mean 'On'. In the grid, the 'On' state is applied to Monday at 0 ap., Tuesday at 0 ap., Wednesday at 0 ap., Thursday at 0 ap., Friday at 0 ap., Saturday at 0 ap., and Sunday at 0 ap. The bottom right corner of the window has a green checkmark button and a red X button.

We have now created a separate alarm for each event. Below is an overall view of each alarm.

START ACCESS CONTROL 1 EVENT

Mirasys Universal Data Driver

Name: START ACCESS CONTROL 1 EVENT	Normal	Text data in UDD4 DEMO	Record video from Testihuone monitor
Description:			
Priority:	Normal		
Requires Acknowledgment:	No		
Viewable in Profiles:	Demo		
Trigger:			
	Text data in UDD4 DEMO Activate at: START ACCESS CONTROL 1 EVENT alarm Deactivate at: STOP ACCESS CONTROL 1 EVENT alarm		
			
Actions:			
	Record video from Testihuone monitor Resolution: 1920x1080 Recording rate: 15/s Pre-event recording: Off Post-event recording: On		
Pre-event recording time:	0 s		
Post-event recording time:	10 s		
Calendar:	The alarm is always enabled		
Special Days:			

START ACCESS CONTROL 2 EVENT

Name: START ACCESS CONTROL 2 EVENT	Normal	Text data in UDD4 DEMO	Record video from XNV-9082R
Description:			
Priority:	Normal		
Requires Acknowledgment:	No		
Viewable in Profiles:	Demo		
Trigger:			
	Text data in UDD4 DEMO Activate at: START ACCESS CONTROL 2 EVENT alarm Deactivate at: STOP ACCESS CONTROL 2 EVENT alarm		
			
Actions:			
	Record video from XNV-9082R Resolution: 3840x2160 Recording rate: 15/s Pre-event recording: Off Post-event recording: On		
Pre-event recording time:	0 s		
Post-event recording time:	10 s		
Calendar:	The alarm is always enabled		
Special Days:			

START ACCESS CONTROL 3 EVENT


Name: START ACCESS CONTROL 3 EVENT	Normal	Text data in UDD4 DEMO	Record video from BOSCH FLEXIDOME
Description:			
Priority:	Normal		
Requires Acknowledgment:	No		
Viewable in Profiles:	Demo		
Trigger:			
	Text data in UDD4 DEMO Activate at: START ACCESS CONTROL 3 EVENT alarm Deactivate at: STOP ACCESS CONTROL 3 EVENT alarm		
			
Actions:			
	Record video from BOSCH FLEXIDOME Resolution: 3072x1728 Recording rate: 15/s Pre-event recording: Off Post-event recording: On		
Pre-event recording time:	0 s		
Post-event recording time:	10 s		
Calendar:	The alarm is always enabled		
Special Days:			

- Click **OK** to confirm alarm creation


Testing text channel alarm

- Start Spotter
- Click **Alarms\Alarms** and select **Show**

Mirasys Universal Data Driver




1. Open used text channel to the work area



1. Download PuTTY
2. Install Putty and start the application
3. Set correct information
4. Click **Open**



Mirasys Universal Data Driver




5. Type needed text to the PuTTY
6. Press **Enter**


The screenshot shows a terminal window titled 'DR-Master - PuTTY'. The window displays the text 'START ACCESS CONTROL 1 EVENT' in white on a black background. The window has standard Windows-style title bar controls (minimize, maximize, close) and scroll bars on the right side.

Mirasys Universal Data Driver

1. Text channel shows received information
2. Event name is shown in the list
3. Alarm list show active alarm




When the text channel receives ending input data, the data is shown in the text channel and alarm is ended



Mirasys Universal Data Driver

The last example shows that the text channel has received validated data



Mirasys Universal Data Driver

3. UDD4Demo.xml

```

<?xml version="1.0" encoding="UTF-8"?>
<root>
<logging>
<level value="2"/>
<additionalDebug value="no"/>
</logging>
<channelConfig>
<linefeed value="0x0d0a"/>
<ignored value="0x00,0x0B"/>
<clearscreen value="-----"/>
</channelConfig>
<validation>
<regex value=".*"/>
</validation>
<uddXmlMapper version="2">
<messageType value="text" parsing="regex">
<message number="1" value="alarm">
    <param number="1" value="([a-zA-Z]+) (.+)" group="1"/>
    <param number="2" value="([a-zA-Z]+) (.+)" group="2"/>
</message>
</messageType>
<constants>
    <array name="Rules" params="AT">
<value>start</value>
<value>stop</value>
</array>
    <array name="AlarmType" params="AT">
<value>temp</value>
        <value>normal</value>
<value>low</value>
</array>
</constants>
<rules>
    <message number="1" value="alarm" alwaysShowText="yes">
<param number="1" reference="1" value="$Rules" operator="eq" id="AT">
            <and number="1" reference="2" value="$AlarmType" operator="eq"/>
            <action number="1" type="event" value="$Rules $AlarmType alarm" />
</param>
</message>
</rules>
</uddXmlMapper>
</root>

```



Mirasys Universal Data Driver

Mirasys Ltd - C1CD, Vaisalantie 2-8, 02130 - Espoo, Finland

Tel +358 (0)9 2533 3300 - info@mirasys.com - www.mirasys.com